








P/N	Connector Figure	Radio Brand	Radio Models
K1		RELM	RPV516A, 599A, Plus/RPU416A, 499A Plus, RP4200
		Kenwood	TK208, TK220, TK240, TK240D, TK248, TK250, TK260, TK260G, TK270, TK270G, TK308, TK320, TK340, TK340D, TK348, TK350, TK353, TK360, TK360G, TK370, TK370G, TK372G, TK373, TK430, TK431, TK2100(ProTalk), TK2102(ProPower), TK2130(ProTalk XLS), TK2160, TK2170, TK2200, TK2202, TK2212, TK2300, TK2360, TK3100(ProTalk), TK3101(FreeTalk XL), TK3102(ProPower), TK3130(ProTalk XLS), TK3131 (FreeTalk XLS), TK3160, TK3170, TK3173, TK3200, TK3201, TK3202, TK3212, TK3230, TK3300, TK3360
		Blackbox	Bantam
		HYT	TC620, TC700EX
M1		Motorola	CP100, CP125, CP150, CP185, CP200, CT150, CT250, CT450, CT450LS, GP2000, GP350 (requires a Motorola HLN9482 adaptor), GP300, GP308, GP280, GP68, GP88, GTI, GTX, LTS2000, P040, P080, P110, P1225, P1225LS, PR400, PRO3150, SP10, SP21, SP50, XTN446, XTN500, XTN600, XV1100, XV2100, XU1100, XU2100, XU2600, VL130, VL50, BPR40, DTR Series
		Blackbox	Blackbox, Blackbox+
		RELM	RP6500
		HYT	TC500, TC600, TC610, TC700
		TEKK	XU100, XV100, XU1000, XV1000
M7		Motorola	TRBO, XPR Series, APX7000 Series
S3		Icom	F3G, F3GS, F4G, F4GS, F11, F11S, F14, F14S, F15, F21, F21S, F22, F24, F24S, F31, F33, F43
Y2		Vertex	MH-360M, MH-450M, MH-50A7A, VH-110, VH-115M, VH-120/130/215M/225M, VX-600, VX-800, VX-900
Y4		Vertex	VX130, VX160, VX180, VX210, VX210A, VX230 Series, VX350, VX400, VX410, VX420, VX351, VX354, VX231, VX451, VX454, VX459
F		Sprint/Nextel	Falcon Series; i205, i215, i265, i275, i285, i305, i315, i325, i335, i355, i365, i415, i450, i465, i530, i560, i570, i576, i580, i605, i615, i670, i680, i710, i720, i730, i733, i736, i740, i760, i776, i830, i833, i835 Roxy, i836, i850, i855, i860 Woody/Tattoo, i870, i875, i880, i890, i920, i930, ic402, ic502, ic602, ic902