



The PRYMEBLU Lapel Microphone has an internal Lithium Ion rechargeable battery pack which must be charged prior to operation, and must be recharged regularly. A fully charged battery will provide approximately 10 hours (or more) of operation before needing to be recharged. However, operating time can vary depending on usage and the condition of the battery pack. Recharge the battery regularly.

STEP ONE: Charging the Bluetooth Lapel Microphone

To charge the PRYMEBLU Lapel Microphone

1. Ensure the PRYMEBLU Lapel Microphone is turned off using the multifunction button.

2. Plug the supplied wall charger into a standard 120 volt AC outlet.

3. Plug the charge cable into the AC wall charger and then into the charge jack on the side of the PRYMEBLU Lapel Microphone. You will need to remove the protective rubber cover that is inserted into the charge jack. (To prevent dust and moisture from damaging your lapel microphone, always ensure this cover is in place when you are not charging the lapel mic.)

4. Once the charging process has begun, the LED indicator on the back of the PRYMEBLU Lapel Microphone will show a constant red light. When the battery is done charging, the LED light will change to a blue color

5. Typical charge time is approximately 2-3 hours. Actual charge time will vary depending on several factors including the battery's charge state, condition, and age

6. Disconnect the charger from the lapel mic when charging is completed.

Charging Cautions:

- Use only the wall charger supplied by the manufacturer. Do not use any other charger.

- Do not use a wall charger that appears to be damaged. (Example: frayed wires, melted plastic, etc.) Contact PRYME to get a new manufacturer-approved replacement charger.

- Do not tamper with or modify the PRYMEBLU Lapel Microphone or charger

-Always turn the power switch to the off position when charging the PRYMEBLU Lapel Microphone. * After pairing is successful, turn off the PRYMEBLU PTT and the two-way radio that the PRYMEBLU Adapter is attached. Wait at least three seconds.





FARPHONE JACK Any standard 2.5 mm mono earphone can be plugged into this jack. Received calls are heard over the earphone's speake

EARPHONE Various available. EH-1169J Shown



When the PRYMEBLU lapel microphone is paired with a PRYMEBLU Adapter, holding this button down activates the Push-to-Talk feature of the two-way radio.

VOLUME UP/DOWN BUTTONS These buttons can be used to set the volume level of the BT-LMIC's earphone



The alligator-type clip secures the PRYMEBLU lapel microphone to the user's clothing during use. The clip can be rotated to allow the mic to be better positioned.



BUILT-IN MICROPHONE This microphone picks up the user's voice audio to send over- the-air



"COVERT" STATUS LED The LED flashes messages that let the user know the current status of the PRYMEBLU lapel microphone

MULTIFUNCTION BUTTON Turns the PRYMEBLU lapel microphone on

and off. Also, used to place the PRYMEBLU lapel microphone in pairing mode so that it can be connected wirelessly to a new PRYMEBLU Adapter or cellular telephone



CHARGE JACK This mini-USB jack is used to connect the supplied charger in order to recharge the PRYMEBLU lapel microphone's internal battery pack

Connecting an Earphone to the Lapel Microphone

2



In order to be able to hear incoming signals received by the two-way radio, the PRYMEBLU Lapel Microphone must be used with an earphone. A PRYME EH-1169J ear bud-style earphone is included with the PRYME Lapel Microphone kit.

STEP TWO: Connecting the Earphone to the Lapel Microphone

1. Plug the earphone into the 2.5 mm audio jack located on the top of the PRYMEBLU Lapel Microphone. Make sure that the connector on the earphone is pushed all the way into the jack on the lapel microphone.

2. You can adjust the volume of received signals by using the Volume Up and Volume Down buttons on the front of the lapel microphone.

Optional Earphones:

Although the BT-LMIC lapel microphone kit includes a PRYME ear bud-style earphone, it is possible to use a different earphone, if you wish. The 2.5 mm audio jack on the lapel mic will accept any mono earphone with a 2.5 mm audio plug.

PRYME makes a variety of listen-only earphones in different styles that will work with the BT-LMIC kit.

Model	Style	Cable Length/Type	Connector
EH-369SC	Rubber Ear Hook	15" Coiled	2.5 mm right-angle
EH-369XC	Rubber Ear Hook	25" Coiled	2.5 mm right-angle
EH-1269SC	Plastic D-Ring	15" Coiled	2.5 mm right-angle
EH-1269XC	Plastic D-Ring	25" Coiled	2.5 mm right-angle
EH-1369SC	Acoustic Tube	15" Coiled	2.5 mm right-angle
EH-1369X	Acoustic Tube	30" Coiled	2.5 mm right-angle
EH-1379X	Acoustic Tube	30" Coiled	2.5 mm straight

These optional earphones are all sold separately. Contact your PRYME Dealer to order.

Pairing With a PRYMEBLU Adapter and 2-Way Radio

LINE ART OF THE BT-LMIC WITH

RADIO WAVE LINES INDICATING

A WIRELESS CONNECTION.]

A TWO-WAY RADIO WITH BT-ADAPTER ATTACHED WITH

STEP THREE: Pairing with a PRYMEBLU Adapter

When pairing the PRYMEBLU Lapel Microphone with a PRYMEBLU Adapter, make sure that the lapel microphone, adapter, and the two-way radio the adapter is connected to are all powered off.

If your PRYMEBLU Adapter gets power directly from the two-way radio it is attached to:

• Hold down the Talk button on the PRYMEBLU Adapter while turning the two-way radio ON.

If your PRYMEBLU Adapter has its own

charger/internal battery pack: • Turn the power switch on the back of the PRYMEBLU Adapter to the ON position while holding down the Talk button on the front of the PRYMEBLU Adapter.

If your PRYMEBLU Adapter gets power from an external source (such as an automobile cigarette lighter jack):

Hold down the Talk button on the front of the PRYMEBLU Adapter while plugging the adapter into the external power source (cigarette lighter jack).

Continue to hold the Talk button on the adapter down for approximately three seconds. Release
the Talk button when the status LED on the PRYMEBLU adapter begins to flash two times per second.
The PRYMEBLU Adapter is now in audio accessory pairing mode.

The PRYMEBLU Adapter is now in audio accessory pairing mode. • Hold down the Multifunction Button on the PRYMEBLU Lapel Microphone. Continue to hold the button down for approximately 3 seconds, until you see the LED on the lapel mic begin to quickly flash RED-BLUE-RED-BLUE. The PRYMEBLU Adapter is now in pairing mode.

 After a few seconds, the two devices should synch to one another. Once the PRYMEBLU Lapel Microphone and Adapter are paired with each other, the status LED on the adapter will show a constant blue light for three seconds. The LEDs on both the adapter and lapel microphone will then show one FLASH every few seconds.

• If the PRYMEBLU Adapter does not detect the lapel microphone within 60 seconds of being put into pairing mode, the adapter will exit the pairing mode and resume normal operation.

Once successfully paired, you will be able to operate your 2-way radio using the PRYMEBLU Lapel microphone.

Reconnecting to a Previously Paired Headset

Once the PRYMEBLU Lapel Microphone and Adapter have been successfully paired together, both devices will remember that connection. The adapter and lapel mic will attempt to reestablish their link whenever when the radio/adapter and headset are both turned on and in within range of each other.

Re-establishing this connection can take 10-60 seconds.Bluetooth headset. Received signals will also be heard through the Bluetooth headset's earphone.

5

Using the BT-LMIC with a Cellular Phone or MP3 Player

Although the PRYMEBLU BT-LMIC Lapel Microphone kit is primarily designed for two-way radio use, it can be paired to a Bluetooth enabled cellular phone or MP3 player in place of a standard Bluetooth headset. In order to pair your lapel mic and cellular phone, do the following:

 First, activate the Bluetooth feature of your cellular phone using the instructions provided by the manufacturer. For most phones, select Settings/Tools > Connections > Bluetooth > On. See your phone's user guide for more information.

• Hold down the Multifunction Button on the PRYMEBLU Lapel Microphone. Continue to hold the button down for approximately 3 seconds, until you see the LED on the lapel mic begin to quickly flash RED-BLUE-RED-BLUE. The PRYMEBLU Adapter is now in pairing mode.

On your phone, chose the newly discovered Bluetooth device as the active connection. See your
phone's user guide for more information.

• If prompted for the Passkey (PIN code), enter 0000. Pairing is successful! You should now be able to use the PRYMEBLU Lapel Mic with your cellular phone.

Note that the PRYMEBLU Lapel Microphone does not support pairing to multiple devices. You can pair the lapel microphone with a PRYMEBLU Adapter / two-way radio OR with a cellular phone, but not both at the same time.

When connected with a cellular phone, the Multifunction Button of the PRYMEBLU Lapel Microphone has the following functions:

BUTTON	FUNCTION	
Multifunction Button	Play / Pause music	
Volume Up	Skip forward to next track	
Volume Down	Skip back to previous track	

When used with an MP3 music player, the following buttons on the PRYMEBLU Lapel Microphone have different functions as well:

CALL STATE	BUTTON PRESS	FUNCTION
Incoming call	Press Multifunction Button once	Answer call
Incoming call	Press Multifunction Button twice	Reject call
On a call	Press Multifunction Button once	Hang up
No active call	Press Multifunction Button twice	Last number redial

Note that you should set the volume level on the PRYMEBLU Lapel Microphone using the Volume Up / Volume Down buttons before connecting the lapel mic to a MP3 music player since the volume control functions are remapped when a music player is connected.

Testing and Using the PRYMEBLU Adapter

Once your PRYMEBLU Lapel Microphone and PRYMEBLU Adapter have been paired together:

Received signals will be heard over your PRYMEBLU Lapel Microphone's earphone. The volume of received calls can be adjusted using the Volume UP and Volume DOWN buttons on the PRYMEBLU Lapel Microphone. The volume can also be adjusted using the volume control on the two-way radio (for most models).

Push-to-Talk can be activated one of several different ways:

By pressing and holding the PTT button on the PRYMEBLU Lapel Microphone.

By pressing and holding the Talk button on the PRYMEBLU Adapter.

Using an optional wired PTT that is compatible with the PRYMEBLU Adapter.
 Using an optional PRYMEBLU Wireless Bluetooth PTT (model BT-PTT, sold separately).

Note that if you are using a PRYMEBLU BT-PTT, you will first need to pair the adapter

with the PTT using the instructions located in the PRYMEBLU PTT User's Guide.

When transmitting, the operator's voice is picked-up by the microphone in the PRYMEBLU Lapel Microphone

STATUS LED MESSAGES

The meanings of the various status LED messages shown by the PRYMEBLU PTT are shown on the following table:

LED INDICATION	MEANING
Two fast blue flashes	Power On or Power Off
Slow blue flash	Normal operation
Flashes red-blue-red-blue repeatedly	Pairing mode
Constant red	PTT is depressed
Slow red flash	Battery low
Constant red (while plugged into charger)	Charge mode
Constant blue (while plugged into charger)	Done charging

SPECIFICATIONS

Version	3.0	
Profiles	HSP, HFP, A2DP, AVRCP	
R.F. Spec	Class 2	
Power	6dB	
Sensitivity	-90d	
Range (typical)	10 meters	
Standy Current	6mA	
Standby Time	50 hours	
Average Talk Time	10 hours	
Operating Temp. Range	-15° C to +50° C	

SUPPORT AND WARRANTY

PRYME Radio Products warrants this product against defects in materials or workmanship for a period of one year from the date of retail purchase. PRYME will repair or replace a defective unit, at our option, without charge for parts or labor. The limited warranty is extended only to the original purchaser and is valid only to consumers in the United States and Canada. It does not cover damage or failure caused by or attributable to Acts of God, abuse, misuse, improper or abnormal usage, faulty installation, improper maintenance, lightning, or other incidences of excessive voltage, or any tampering or repairs by other than a PRYME authorized repair facility. It does not cover replacement of consumable parts, transportation costs, or damage in transit.

Repair or replacement under the terms of this warranty does not extend the terms of this warranty. This warranty can only be modified by an officer of PRYME Radio Products, and then only in writing. Should this product prove defective in workmanship or material, the consumer's sole remedies shall be such repair or replacement as provided by the terms of this warranty. Under no circumstances shall PRYME Radio Products be liable for any loss or damage, direct, consequential, or incidental, arising out of the use of or inability to use this product. Some states do not allow limitations on how long an implied warranty lasts or the exclusions or limitations of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights. You may also have other rights, which may vary, from state to state.

For support or warranty service on your PRYME product, contact us at 1-800-666-2654 or visit us on the web at www.PRYME.com.

COPYRIGHT AND TRADEMARK INFO

© 2012 PRYME Radio Products, Brea CA. All rights reserved.

PRYME® and PRYMEBLU™ are trademarks owned by PRYME Radio Products. All other product or service names are the property of their respective owners.

DISCLAIMER: The Bluetooth wireless link used by PRYMEBLU products is an open standard, unsecured technology. As such, it is not recommended for first-responder or other mission critical users.